



## Test Monitoring Center

6555 Penn Avenue  
Pittsburgh, PA 15206-4489  
(412) 365-1000

MEMORANDUM: 08-001  
DATE: January 23, 2008  
TO: L-33-1 Surveillance Panel  
FROM: Donald Lind  
SUBJECT: Pre-Test Mixing of Test Oil

During the January 11, 2008 L-33-1 Surveillance Panel teleconference meeting, the panel requested the TMC to issue a memorandum to assure that all labs shake or mix the test oil the same way prior to use. Effective immediately, all labs will first vigorously shake the test oil can in its upright position and then rotate it upside down and vigorously shake again. The procedure shall be done prior to pouring the test oil for use and shall take approximately one minute.

DML/dml

Attachments

c: Frank Farber, TMC  
John L. Zalar, TMC

<ftp://ftp.astmtmc.cmu.edu/docs/gear/1331/memos/mem08-001.pdf>

Distribution: email