Sequence X ASTM D8729

Ford Chain Wear Test Surveillance Panel Meeting

August 9, 2022

Prepared By: Alfonso Lopez, S.P. Chairman

Sequence X Surveillance Panel Meeting Agenda 08/09/22

- Roll call
- Approval of the meeting minutes 06/21/22
- Hardware Update (2028)
- TMC Update Reference Oil Status
 - Oil 271 Suspension
- Continue discussion oil 271 options

Meeting Minutes

- Recent data from Lad D on oil 270
 - First test was 3 sigma mild. Repeat test was .7 sigma mild.
 - No operational comparison of the two tests has been performed. Joseph reported no understanding of why the
 tests were different in severity.
- Continued discussion of oil 271 and the mild trend
 - Statistician group recommendation to increase reference oil standard deviations was discussed in previous meeting with concern. See minutes for detail. Presentation below.
 - Andy proposed using oil 271 as a discrimination oil only. The Sequence IX test uses oil 220 in a similar manner to confirm the stand can discriminate.
 - Doyle proposed that the discrimination runs not be charted or used for severity adjustment calculations.
 - The re-blend of oil 1011-1 has been put on hold due to the mild trend. It has become standard practice to generate test data on new blends to confirm existing targets. The group agreed that the 1011-1 blend should not be introduced at this time. Stock of oil 270 will carry the test through another 10 years.
 - The oil inventory situation results in labs using oil 270 to calibrate and oil 271 to prove discrimination. A proposal was made to run back-to-back tests. To grant calibration status, oil 270 would be used to establish a control chart acceptance and oil 271 would be used to prove that the stand can discriminate.
 - The level of discrimination or delta will be calculated by the statistician group for review at the next meeting.
 - Rich was tasked to word a motion for the proposed calibration/discrimination strategy. The motion will be voted
 on at the next meeting.
 - Next meeting 08/16/22

Reference Oil Update

Oil 271 Suspension 04/08/21 – Present

- Oil 1011 Depleted
 - 1011-1 Assignment on hold pending severity shift resolution
- Oil 270 all stand calibrated on oil 270 for past year. Inventory of oil is approximately 625 gallons

Hardware Update

Fuel

- EEE (137K gal) Next Batch in August
- Alternative fuel testing on hold pending severity shift resolution

Hardware

- Labs received quote from Ford Component Sales (FCS) for non-critical hardware
- Critical hardware group purchase in progress only independent labs purchasing critical hardware.
- Test life planned through 2028

Sequence X Severity Mathematical Corrective Options

Statistics Group


June 2021

Statistics Group

- Doyle Boese, Infineum
- Jo Martinez, Chevron Oronite
- Martin Chadwick, Intertek
- Phil Scinto, Lubrizol
- Richard Grundza, TMC
- Todd Dvorak, Afton
- Travis Kostan, SwRI

Background

All 3 reference oils appear to have shifted by similar CHST amount. Therefore Ln(CHST) more greatly impacted Oil 271. Oil 271 has been temporarily suspended.



Executive Summary

The statistics group has ordered potential test severity remedies below in order from most to least preferred.

- 1. Return the test to traditional severity levels through an engineering solution.
- 2. Continue the suspension of reference oil 271.
 - The remaining 2 oils can still track test severity in both the mild and severe direction, and are not causing problems with lab calibration.
 - Some options exist for running 271 on a less frequent basis and not for calibration. This can be explored/discussed further if the panel desires.
- 3. If a mathematical solution is desired, the majority preference of the statistics group is to update the reference oil standard deviations as shown in the table below. To prevent an overly large influence of oil 271 on the severity adjustment standard deviation, the stats group recommends using the oil 270 standard deviation as the standard deviation for severity adjustments. This is appropriate if one believes candidate results near the performance of oil 271 have not seen as large a shift in transformed units.

Oil	Current S.D.	New S.D.
270	0.17435	0.24011
271	0.17537	0.56272
1011	0.18882	0.27434
Severity Adj. S.D.	0.17856	0.24011*

Recommendations if Increased's Adopted

- Conduct additional tests on RO271 prior to implementing any changes. At least one test per lab is recommended.
 - The last 271 runs with the current procedure were in Feb-2021 and at least one lab may have shifted performance on 270 since then.
- Increase reference frequency as long as standard deviations that incorporate bias are used and perform regular reviews of the data.
 - The LTMS will not work as intended if standard deviations that incorporate bias are used for ei and Zi calculations. Any future shift in severity will be less likely to be detected while this correction is in use. It is critical that we collect more data than when the process is performing as expected to increase the chance of developing a correction that is more effective long term and to reduce the risk that a new shift in severity occurs that is not appropriately addressed by the severity adjustments resulting from the new calculations.


Mathematical Corrective Options Considered

The following are a list of options for mathematical corrective options evaluated (in no particular order). Fixing a problem mathematically for the reference oils does not mean that the underlying problem will be fixed for candidate oils.


- 1. Re-evaluate the transformation based on the current data set. If different from Ln, calculate new means and standard deviations. Also consider removing the transformation from Oil 271 only. Would require new mean and standard deviation for this oil.
 - **Result** A square root transformation was slightly preferred over the natural log but provided only small relief. This fix would likely be needed in addition to a standard deviation adjustment, and fewer changes are preferred to many.
- 2. Correction factors. This would be applied equally to all oils, candidates and references. Evaluate constant and proportional correction factors to transformed and untransformed results.
 - **Result** Constant correction factors in untransformed units were reasonable, but slightly over- and under-corrected some reference oils. Proportional correction factors bring all oils back to target, but results in large positive corrections for mild oils, requiring strong belief that candidates near oil 271 performance are behaving similarly. For any correction factor options, the lack of root cause also makes starting/stopping point of correction factor implementation unclear.
- 3. Calculate new standard deviations. This will make the standard deviation of 271 larger and thus bring the standardized result closer to target.
 - *Result* This option was chosen, as it provides relief to the test while requiring the least amount of changes to the way the test has been run historically.

When Did the Shift Occur?


Because we have been unable to tie the shift in severity to any particular change in the test, we do not have clear guidance as to how we draw the line in the sand. The following slides will discuss each of the 3 options below.




Line #1 is suggested as the best split according to a partition analysis (08/08/19). After this date we began to see some of the lowest results even seen on oil 270.



Split #2 is based on the date of the first data of an extreme mild 271. The other 271 from the same day would go in the pre-shift group.




Split #3 appears to be the split which best captures the point in time when all 3 oils were producing almost exclusively mild results.



-Fuel Batches


The data was colored by fuel batch ID to investigate how the timeline aligns with fuel batch changes. Split #1 lines up fairly well with change to "H" batch, while split #3 lines up with change to "N" batch.

#1 #2 #3



-Lab Differences

The plot below shows Lab G showed the first evidence of the shift among labs after split #1.



Standard Deviation Update

New Standard Deviations

Below are some comparisons of options for new standard deviations. The standard deviation update using "Post #1" was preferred.


Oil	Current S.D.	S.D. Post #1	S.D. Post #3	S.D. All Data	
270	0.17435	0.24011	0.21619	0.19023	
271	0.17537	0.56272	0.77157	0.33291	
1011	0.18882	0.27434*	0.24701*	0.21735	
Pooled	0.17856	0.39913	0.46779	0.25746	
Recommended		0.24011**			

^{* -} Actual was 0.37932. However, with only 4 data points in Post #1 and Post #3, it seemed more appropriate to estimate using the ratio observed with the "All Data" standard deviation for 270/1011 (0.21735/0.19023).

^{** -} Standard deviation of oil 270

Updating Yi Using Post #1 S.D.

Yi's after 08/08/2019 here shown with updated standard deviations for Post #1 period.



Impact of Updated Severity Adjustment S.D.

The table to the right indicates how candidate results will be adjusted on a stand with a Zi value of -1 with the updated pooled SA of 0.24011.

СНЅТ	Ln(CHST)	Ln(CHST)+0.24011	CHST FNL
0.010	-4.6052	-4.3651	0.013
0.020	-3.9120	-3.6719	0.025
0.030	-3.5066	-3.2664	0.038
0.040	-3.2189	-2.9788	0.051
0.050	-2.9957	-2.7556	0.064
0.060	-2.8134	-2.5733	0.076
0.070	-2.6593	-2.4192	0.089
0.080	-2.5257	-2.2856	0.102
0.090	-2.4079	-2.1678	0.114
0.100	-2.3026	-2.0625	0.127
0.110	-2.2073	-1.9672	0.140
0.120	-2.1203	-1.8802	0.153
0.130	-2.0402	-1.8001	0.165
0.140	-1.9661	-1.7260	0.178
0.150	-1.8971	-1.6570	0.191


Appendix

Re-evaluation of the Transformation

Re-evaluating the transformation

-Using All Data with "Pre" or "Post" added to Model


Partition analysis suggests best split at 08/08/19. All data in in right box labeled as "Post." All other data labeled "Pre". Then modeled CHST ~ Oil, Lab, Stand[Lab], Pre/Post. Square root transformation more appropriate here.



Re-evaluating the transformation

-Using All Data with "Pre" or "Post" added to Model


All data in in right box labeled as "Post" (except for first near target 271). All other data labeled "Pre". Then modeled CHST ~ Oil, Lab, Stand[Lab], Pre/Post. Square root transformation more appropriate here.



Re-evaluating the transformation

-Using All Data with "Pre" or "Post" added to Model

All data in in right box labeled as "Post" All other data labeled "Pre". Then modeled CHST ~ Oil, Lab, Stand[Lab], Pre/Post. Square root transformation more appropriate here.



Sqrt. Transformed Targets -Averages

In order to keep the pivot point the same for positive and negative severity adjustments, the original targets were back-transformed into original units, and then the square root transformation is applied to obtain the target Sqrt(CHST) for each oil.

Reference Oil	Target Ln(CHST)	Target CHST	Target Sqrt(CHST)
270	-2.15699	0.1157	0.34011
271	-2.60987	0.0735	0.27119
1011	-2.08191	0.1247	0.35312

Sqrt. Transformed Targets -Standard Deviations


Standard Deviation #1 – For each Oil, Calculated Std. Dev. of (Result-Target). Used n=71 data set prior to any evidence of the mild shift (labeled "Pre #1" in previous slide).

Standard Deviation #2 – For each Oil, Calculated Std. Dev. of (Result-Target). Used all data.

Reference Oil	Target Sqrt(CHST)	Std. Dev. 1	Std. Dev. 2
270	0.34011	0.02784	0.03116
271	0.27119	0.02298	0.03421
1011	0.35312	0.03023	0.03343
Pooled		0.02681	0.03281
Average		0.02702	0.03293


Plot of CHST Yi Using Sqrt. With SD#1

Below is a plot of the CHSTYi when calculated using the standard deviation of the data "PRE #1" data only with the square root transformation.



Plot of CHST Yi Using Sqrt. With SD#2

Below is a plot of the CHSTYi when calculated using the standard deviation calculated using all of the data and the square root transformation.



No Transformation for Oil 271

- For Oil 271, the mean of untransformed result is the back-transformed current mean for Ln(CSHT).
- Standard deviation of (result-mean) is calculated using the 271 untransformed data from data set "Pre 1" only.
- No changes to oil 270 or oil 1011.


Oil	CHST Mean	Standard deviation
271	0.0735	0.0125

Same as current LTMS for these oils

Oil	Ln(CHST) Mean	Standard deviation
270	-2.15699	0.17435
1011	-2.08191	0.18882

271 New Yi's

The graph below shows how the 271Yi values would change without the transformation.



Correction Factors

Pre- and Post-Transformation Options

Some Constant Correction Options


Below are some options for corrections to be applied to all tests depending on when you choose to identify the start of the shift and the type of correction factor you wish to apply (before of after transformation).

C.F. Number	Model	Pre LS Mean	Post LS Mean	Post Correction Factor (To "Pre")	Post Correction Factor (To Target)*
1.	CHST ~ Oil, Lab, Stand[Lab], Pre/Post #1	0.1047	0.0785	+0.0262	+0.0253
2.	CHST ~ Oil, Lab, Stand[Lab], Pre/Post #2	0.1021	0.0785	+0.0236	+0.0249
3.	CHST ~ Oil, Lab, Stand[Lab], Pre/Post #3	0.1024	0.0740	+0.0284	+0.0296
4.	Ln(CHST) ~ Oil, Lab, Stand[Lab], Pre/Post #1	-2.28375	-2.62183	+0.33808	+0.33073
5.	Ln(CHST)~ Oil, Lab, Stand[Lab], Pre/Post #2	-2.31325	-2.63989	+0.32664	+0.34451
6.	Ln(CHST) ~ Oil, Lab, Stand[Lab], Pre/Post #3	-2.31344	-2.68375	+0.37031	+0.39137

^{*}Calculated by using the prediction equation to predict average performance across all lab-stands in the "post" period (did not use nested stand term here, but lab-stand).


Ln(CHST+CF) with Measurement Correction Factor #1 -Corrected To Target

Reference tests shown below on of after 08/08/2019 have the measurement correction factor of ± 0.0253 applied.




LN(CHST+CF) with Measurement C.F. #1

Reference tests shown below on of after 08/08/2019 have the measurement correction factor of ± 0.0253 applied.




Ln(CHST+CF) with Measurement Correction Factor #3 -Corrected To Target

Reference tests shown below on of after 06/28/2020 have the measurement correction factor of +0.0296 applied.




LN(CHST+CF) with Measurement C.F. #3

Reference tests shown below on of after 06/28/2020 have the measurement correction factor of ± 0.0296 applied.




Ln(CHST)+CF with Correction Factor #4

Reference tests shown below on of after 08/08/2019 have the post-transformation (typical application) correction factor of +0.33073 applied.




Ln(CHST)+CF with Correction Factor #4

Reference tests shown below on of after 08/08/2019 have the post-transformation (typical application) correction factor of ± 0.33073 applied.



What about a non-constant C.F.? -Using Post #1 & #3 Modeled Means

The below shows how the correction factor would increase with improved oil performance. This assumes candidates are showing the same trend as the reference oils by level.




Correction factors by CHST Level

The table below shows how the CHST values would adjust when using a level dependent correction factor.

CHST	Ln(CHST)	C.F. w/ Post #1	Adj. CHST w/ Post #1	C.F. w/ Post #3	Adj CHST w/ Post #3
0.010	-4.6052	0.9317	0.025	1.2995	0.037
0.020	-3.9120	0.7236	0.041	0.9755	0.053
0.030	-3.5066	0.6019	0.055	0.7859	0.066
0.040	-3.2189	0.5155	0.067	0.6514	0.077
0.050	-2.9957	0.4485	0.078	0.5471	0.086
0.060	-2.8134	0.3938	0.089	0.4619	0.095
0.070	-2.6593	0.3475	0.099	0.3898	0.103
0.080	-2.5257	0.3074	0.109	0.3274	0.111
0.090	-2.4079	0.2721	0.118	0.2723	0.118
0.100	-2.3026	0.2404	0.127	0.2231	0.125
0.110	-2.2073	0.2118	0.136	0.1785	0.131
0.120	-2.1203	0.1857	0.144	0.1378	0.138
0.130	-2.0402	0.1617	0.153	0.1004	0.144
0.140	-1.9661	0.1394	0.161	0.0658	0.150
0.150	-1.8971	0.1187	0.169	0.0335	0.155


New Ln(CHST) and Yi w/ Post #1

The table below shows how data after 08/08/2019 would change with the level-dependent correction factor.



New Ln(CHST) and Yi w/ Post #3


The table below shows how data after 06/28/2020 would change with the level-dependent correction factor.



More Standard Deviation Options


Updating Yi Using Post #3 S.D.

Yi's after 06/28/2020 here shown with updated standard deviations for Post #3 period.



Updating Yi All Data Standard Deviations

All tests below have been corrected using the updated standard deviations calculated with all data.



Sequence X History

Sequence X Milestones					
1/1/2012	Start of Chain Wear Test Development				
12/7/2017	AOAP Approval for GF6				
4/2/2018	Live Registration (03/19/16 Retro - Registration)				
2/20/2019	Surveillance Panel Procedure Acceptance Vote				
4/4/2019	Subcommittee B Ballot				
6/16/2019	Main Committee D02 Ballot - ASTM Procedure D8279				
11/7/2019	Memorandum 19-043 Use of Calibrated Sequence X Stands to Generate Used Oil Samples for Seq IX (LSPI)				
11/20/2020	Information Letter 20-1 Procedure Edits / Drive Shaft Spec				
1/27/2020	Information Letter 20-2 Criteria for Multiple Test Type Calibration				
6/1/2020	Mild Severity Shift Task Force Formed				
9/11/2020	Information Letter 20-3 Correction to Table 12				
10/14/2020	Information Letter 20-4 (1) Correcting PCV Flow Meters (2) Correction to Section 12.1.1				
4/8/2021	Oil 271 Suspended from use due to mild results				
9/17/2021	Information Letter 22-1 Engine run limits, honing procedure, connecting rod orientation, blowby gas thermocouple orientation				