

**L42-1 task force conference call  
11-18-2005**

C. Koglin  
S. Marty  
D. Lind  
D. Smith  
D. Bartlett

**L42-1 updates**

Section 6.6.1

All labs to go back & set T/C depth with table top method. Labs to check clearance between T/C and ring gear.

Labs checked and everyone is 3/16" to 3/8" away from ring gear. OK by group.

Words "use a 1/8 in. diameter J or K type closed tip style thermocouple" will be added to section 6.6.1.

All Labs to check on Dana Manual version

Lab manual version OK, no changes made.